

DSP-G5_BA 09-2017 Seite 1

Montageanleitung Gewinde (-G5) für MultiSafe DSP 5 / DSP 5B / DSP 5ST

Vor der Montage müssen die Spitzen des Gerätes zum Kleben staubfrei, sauber und trocken sein. Bei Bedarf können diese mit Isopropanol / Alkohol gereinigt werden.

1. Gewinde Set (84024) bestehend aus 2 gleichen Teilen



2. Sekundenkleber auf die Gerätespitze auftragen



3. Gewinde aufstecken und andrücken



4. Sekundenkleber auf die Griffspitze auftragen



5. Gewinde aufstecken und andrücken



6. Fertig montierter Gewindesatz



Für 30 Minuten nicht benutzen!



DSP-G5_BA 09-2017 Page 1

Installation instructions thread (-G5) for MultiSafe DSP 5 / DSP 5B / DSP 5ST

Before assembly, the tips of the device must be dust-free, clean and dry for gluing. If necessary, these can be purified with isopropanol / alcohol.

1. Thread set (84024) consisting of 2 equal parts



2. Apply a superglue to the device tip



3. Mount thread and press



4. Apply a superglue to the handle tip



5. Mount thread and press



6. Fully assembled thread set



Do not use for 30 minutes!